

Interconnecting wiring diagram only.




Connection Settings.

- 1/ Floats switches from OLE are Normally Closed (NC) when in DOWN position.
- 2/ The T4000 inputs can be switched from NC to NO as required using the 2 jumpers on each circuit.
- 3/ The 0/1 jumper can be removed to disable the Alarm circuit. (No LED)
- 4/ The P and A jumper are for when the system is being used as a Pump controller or as an Alarm.
- 5/ H+ H- is for an Audible Alarm that will activate when Flashing RED condition is present. (This is the supply voltage so 24vdc)

Operation:

- 1/ When lights are GREEN = No Alarm
- 2/ When Lights Flash RED = Alarm / problem. (ORANGE = PUMP ON)
- 3/ When the Acko button is pressed the Lights changed to fixed RED
This Auto resets when Alarm condition is removed.
- 4/ The BMS output changed condition (Volt Free) when any of the alarms are flashing red or solid red.
- 5/ The P and A jumper are for when the system is being used as a Pump controller or as an Alarm.
- 6/ When in Pump Control mode, Relay OUTPUTS 2 and 3 are NOT operational
- 7/ When Input 4 is in "P" (Pump Control) This also SHUTS DOWN the PUMP CIRCUIT **FAIL SAFE**



Description .
T4000 STANDARD
CONNECTING WIRING
REQUIREMENTS

DRG No T4000-STD WIRING

Date 11-02-2015
Rev No 01